

FIBERME Communications LLC.

FCM630A Series IP PBX - Announcement Center Guide

Table of Contents

INTRODUCTION	3
ANNOUNCEMENTS CENTER SETTINGS	4
Announcements Center Settings	
Group Settings	5
CONFIGURING ANNOUNCEMENT CENTER	6
ANNOUNCEMENT CENTER EXAMPLE	8
Configuration Steps	9
Creating Announcement Group	9
Creating Announcement Centers	9
CREATE CUSTOM PROMPTS FOR ANNONCEMENTS CENTER	11
Record New Custom Prompt	11
Upload Custom Prompt	11



Table of Tables

Table 1: Announcement Center settings	4
Table 2: Group Settings	5
Table of Figures	
Figure 1: Announcement Center Flow	3
Figure 2: Announcement Center Settings	4
Figure 3: Announcement Center Group Configuration	6
Figure 4: Announcement Center Creation	7
Figure 5: Announcement Center Created	
Figure 6: Creating Group Room201	9
Figure 7: Creating Announcement Center Emergency	10
Figure 8: Create Announcement Prompt	11
Figure 9: Record New Custom Prompt	11
Figure 10: Custom Prompt List	12
Figure 11: Upload Custom Prompt	12



INTRODUCTION

FCM630A series introduced "Announcement Center" feature allowing to initiate calls and play a preconfigured voice prompt to extensions within same group.

When the code and the group number are dialed together in the combination of code + group number, the specified voice message is sent to all group members and only extensions in the group will hear the voice message.

Announcement center feature can be used in different scenarios such as in hospitals (Code Blue), companies, supermarkets...

This guide will help to understand announcement center settings, steps needed to configure this feature, how to create and upload custom prompt to be used within the announcement center feature, and gives an example illustrating the utility of this option.




Figure 1: Anno uncement Center Flow



Page 3 www.fiberme.com

NNOUNCEMENTS CENTER SETTINGS

The announcement center settings are available on the FCM630A Web GUI under PBX > **Value-added Features** > **Announcement center** as displayed on the figure bellow:




Figure 2: Announcement Center Settings

The following tables describes needed options to configure a new announcement center and a new group.

Announcements Center Settings

Table 1: Announcement Center settings

Name	Configures a name for the newly created Announcements Center to identify this announcement center.
Code	Configures a code number for the custom prompt. This code will be used in combination with the group number. For example, if the code is 55, and group number is 666. The user can dial 55666 to send prompt 55 to all members in group 666.
	Note : The combination number must not conflict with any number in the system such as extension number or conference number.
Custom Prompt	This option is to set a custom prompt as an announcement to notify group members. The file can be uploaded from page 'Custom Prompt'. Click 'Prompt' to add additional record.
Ring Timeout	Configures the ring timeout for the group members. The default value is 30 seconds.



Page 4 www.fiberme.com

Group Settings

Table 2: Group Settings

Name	Configure a name for the newly created group to identify the group
Number	Configure the group number. The group number is used in combination with the code. For example, if group number is 666, and code is 55. The user can dial 55666 to send prompt 55 to all members in group 666. Note: The combination number must not conflict with any number in the system such as extension number or conference number



Page 5 www.fiberme.com

CONFIGURING ANNOUNCEMENT CENTER

Please refer to following steps in order to configure the announcement center on the FCM630A series:

Creating New Group:

- Access the web GUI of your FCM and navigate to PBX > Value-added Features >
 AnnouncementCenter
- 2. Click on Create New Group to create new group.
- 3. Specify the name of the newly created group.
- 4. Configure group number which it will be used with code to send voice message.
- 5. Select the extensions to be included in the group, who will receive the voice message.




Figure 3: Announcement Center Group Configuration

In the example illustrated on Figure 6, the group "Announcement_01" has number 666. Extension 3001, 3002 and 3003 are in this group.

Creating New Announcements Center

- Access the web GUI of your FCM and navigate to PBX > Value-added Features >
 AnnouncementCenter
- 2. Click on Create New Annoucements Center to create a new announcement center.
- 3. Specify the name to the newly created announcement center.
- 4. Configures the code which will be used with group number to send the voice message to.
- Select the message that will be used by the code from the custom prompt drop down menu. To create a new Prompt, please click "Prompt" link and follow the instructions in that page. (Please refer to: <u>Create Custom Prompts for Announcements Center</u>).



nge 6 www.fiberme.com




Figure 4: Announcement Center Creation

Code and Group number are used together to direct specified message to the target group. All extensions in the group will receive the message. For example, we can send code 55 to group 666 by dialing 55666 from any extension registered to the FCM630A. All the members in group 666 which are extension 3001, 3002 and 3003 will receive this voice message after they pick up the call.




Figure 5: Announcement Center Created

Note: The combination number must not conflict with any number in the system such as extension number or conference number



ANNOUNCEMENT CENTER EXAMPLE

In a hospital where FCM630A is installed, "Announcement Center" feature can be used as "Code Blue" service.

"Code Blue" is mainly used in hospitals to indicate a patient requiring resuscitation or immediate medical attention. Instead of announcing on the speakers that there is an emergency in room XXX and disturb the whole hospital.

Using "Announcement Center" feature on FCM630A will allow to dial a code with room number of the patient and hang up, then calls will be initiated (with caller ID as room number) to specified group including doctors, nurses... and once answered, pre-recorded voice messages will be played indicating urgency level and room to go to.

To fulfill these requirements, administrator can create different announcement centers and different groups as follows:

Code	Name	Voice prompt
00	CPR	Immediate attention required - CPR
01	Nurse_requested	Nurse requested
02	Doctor_requested	Doctor requested
03	Consultation	Doctor requested for consultation
04	Emergency	Emergency doctors and nurses requested

Group / Room Name	Extension	Members
Room 201	201	2009,3000,3003,3004, 3002
Room 202	202	2009, 3010, 3020
Room 203	203	3002, 3010, 3025
Consultation Room 01 (General)	301	2002, 2010
Consultation Room 02 (Cardio)	302	2003, 2011, 2012
Emergency Room 01	401	2020, 2021, 2030, 2031, 2032, 2033
Emergency Room 02	402	2040, 2041, 2042, 2043

Once configured, users can dial following combinations:

	Results		
Dial number	Caller ID (Room number)	Extensions ringing	Voice prompt played after pickup
00201	201	2009, 3000, 3002	Immediate attention required – CPR
04401	401	2020, 2021, 2030, 2031, 2032, 2033	Emergency doctors and nurses requested
01201	201	2009, 3000, 3002	Nurse requested
03302	302	2003, 2011, 2012	Doctor requested for consultation

Note: If an extension member of a group picks up the call, other extensions will continue ringing until each extension picks up.



a g e 8 www.fiberme.com

Configuration Steps

Before configuring the group announcement, administrator needs to record or upload the custom promptsto be played when receiving patient's call.

Please refer to Create Custom Prompts for Announcements Center for more details.

Creating Announcement Group

- 1. Access the web GUI > PBX > Value-added Features > Announcement Center.
- 2. Click on to create new announcement group.
- 3. Configure the name of the group as "Room1" for example.
- 4. Set the group number to "201" for example.
- 5. Select the extensions to be included in the group. In this example: extensions2009,3000,3003,3004 and 3002 as displayed on the following figure.




Figure 6: Creating Group Room201

6. Press Save button.

Now we have created the announcement group "Room201" for room 201, we can create other similar groups for the other hospital's rooms using the same steps.

Creating Announcement Centers

- 1. Access the web GUI >PBX > Value-added Features > Announcement Center.
- 2. Click on Create New Annoucements Center to create a new announcement center.
- 3. Set the name to the newly created announcement center to "Emergency".
- 4. Configure the code **04** which will be used with group number to send the voice message to.
- 5. Select the voice prompt to use from the custom prompt drop down menu. In this example, "Emergency.gsm" is selected as displayed on the following figure.



nge 9 www.fiberme.com




Figure 7: Creating Announcement Center Emergency

6. Press Save button.

Now we have created the announcement center "Emergency" with code 04, we can create other similar announcement centers using the same steps.



Page 10 www.fiberme.com

CREATE CUSTOM PROMPTS FOR ANNONCEMENTS CENTER

Prompts on the FCM630A can be customized/personalized at customer's convenience by either recoding or uploading new prompts.

Click on "Prompt" option as shown on the following figure to be redirected to "Custom Prompt" page, or go to Web GUI->PBX->Internal Options->Custom Prompt page directly.




Figure 8: Create Announcement Prompt

Once the prompt file (created/uploaded) is successfully added to the FCM630A, it will be shown in the prompt list options to select in different announcements scenarios.

Record New Custom Prompt

In the FCM630A web UI->**PBX**->**Internal Options**->**Custom Prompt** page, click on "Record New Custom Prompt" and follow the steps below to record new IVR prompt.

- 1. Specify the custom prompt file name.
- 2. Select the format (GSM or WAV) for the IVR prompt file to be recorded.
- 3. Select the "Extension" to receive the call from the FCM630A to record the IVR prompt.




Figure 9: Record New Custom Prompt

- 4. Click the "Record" button. A call will be initiated to the selected extension.
- 5. Pick up the call and start the recording following voice prompts.
- 6. The recorded file will be listed in the IVR Prompt web page (see figure 4). Users could select to rerecord, play or delete the recording.



Page 11 www.fiberme.com




Figure 10: Custom Prompt List

Upload Custom Prompt

If the user has a pre-recorded IVR prompt file, click on "Upload Custom Prompt" in Web GUI under **PBX >Internal Options > Custom Prompt** page to upload the file to the FCM630A.

Following are IVR prompt requirements to be accepted by FCM630A series:

- PCM encoded.
- 16 bits.
- 8000Hz mono.
- In .mp3 or .wav format; or raw/ulaw/alaw/gsm file with .ulaw or .alaw suffix.
- File size under 5M.




Figure 11: Upload Custom Prompt

Click on to select audio file from local PC and click on to start uploading it. Once uploaded, the file will appear in the "Custom Prompt" web page.



Page 12 www.fiberme.com